






HOOK





9x3 mm
9x4 mm



BAYONET




SIDE PIN




PINCH TAB




アダプター交換
Adapter Replacement



TOP LOCK




アダプター交換
Adapter Replacement




PUSH BUTTON

19 mm





アダプター交換 Adapter Replacement



BAYONET RN




アダプター交換
Adapter Replacement




PIN LOCK



アダプター交換
Adapter Replacement




PUSH BUTTON




16 mm



アダプター交換 Adapter Replacement



CLAW



アダプター交換
Adapter Replacement

